CASTORMIX®

Silage unloader - Recycling mixer Feeder - Straw bedder Wrapped silage with long strands



A multipurpose range in the mixing's service !

The Castormix range has been designed for answering your more specific needs : 4 volumes from 6 to 18 m3, 2 kinds of beater bars, 2 kinds of loading (door or claw). Our recycling mixers benefit from the advantages of the Castor+ range : Castor+ beater bar, universal chute, bed-chain.

All these equipments bring you security and efficiency at work :

- Load easily by silage unloading or with self-loading door
- Reach quickly an aired and supple mixing
- Feed and spread straw serenely
- Save time and reduce your costs

Choose a multipurpose machine, simple to load, ideal for mixing, feeding and straw-bedding !

ABEILLE® 12 - 12 m³

8001 8540

CASTORMIX®+ 180 - 18 m³

CASTORMIX®+ 60 - 6 m³

CASTORMIX®+ 80 - 8 m³



Couple your machine rapidly and drive easily !





Choose the coupling corresponding to your machine and to your needs !

Articulated coupling



It adapts to all machines and allows manoeuvrability and comfort by driving. The machine follows completely the tractor.

For Castormix[®]+ 60 and 80

Fixed coupling



With adjustable jib in 3 positions Standard for Castormix[®]+ 180 and Abeille[®] 12. Optional equipment for Castormix[®]+ 60 and 80.

Hydraulic stand



To stabilize your machine, on fixed coupling.

Start and drive your Castormix

Comfort control C



You can reach all functions with 3 fingers. Drive instinctively and supervise your work

Manual control



Economy in control's service. Only for Abeille[®] 12

Multi-functional display



Controls adapted to your expectations !




A complete range, from 6 to 18 m³

Castormix[®]+ 60




A machine of 6m³ equipped with : 1 Castor®+ beater-bar for wrapped silage with long strands



Abeille[®] 12



A machine of 12m³ equipped with : 3 Abeille[®] beater-bars for short strands





Choose a recycling mixer adapted to your needs : Different volumes, claw or lifting rear door




Universal chute and mixing canopy



Round silage unloading claw




Lifting rear door





A machine of 8m³ equipped with : 2 Castor[®]+ beater-bars for wrapped silge with long strands




Castormix[®]+ 180/Abeille[®] 180



A machine of 18m³ equipped with :

- Either 3 beater-bars Castor®+ for wrapped silage with long strands
- Or 3 beater-bars Abeille[®] for short brands.







Load with a claw...

Olny for Castormix[®]+ 80 and 60

Unload silage and load simply



Claw for silage unloading



Reliable and strong



Claw jacks located above the arm in order to avoid contact with the silage



Loading



For an optimized loading

- A clean silage unloading : rounded claw mit automatic scraper

- A material falling in the machine : rounded claw and limited space between the claw and the tub
- A better lifespan : arm and rigid claw



No tub buckling for a longer life by using Machine girders in U form to protect the machine.

Equipments to help you

Mixing hopper 500 L



For adding your dry foods, we propose a mixing hopper 500 L. Available for Castormix®+ 60



(optional equipment for Castormix[®]+ 60) For a better visibility during loading operation

Clean silage unloading deflector kit



To avoid the loss of fodder. It enables a better approach to the silage. Available for Castormix®+ 80 et 60.



... as well as with a lifting rear door

Only for Castormix®+ 180 / Abeille® 180

The doors

Lifting rear door



Only for Castormix[®]+ 180 /Abeille[®]180

Hydraulic rear door



Only for Abeille® 12

Dimensions of the models

Castormix®+ 60



l : 5,09 m - L : 2,40 m - H : 2,33 m

Abeille®+ 12



Performances Castormix®

Castormix®+ 80

Castormix®+ 180



Castormix®+ 60 Castormix®+ 80 Abeille[®] 12 Castormix®+ 180 Feeding or straw-bedding Loading capacity Round bales hay or straw 2 1 1 Ø maxi 2 m Cubic bales hay or straw + 1 on the rear door 1 1 2 1,2 x 0,9 x 2,5 m Square bales hay or straw + 1 on the rear door 1 1 2 1,2 x 1,2 x 2,5 m Round bales wrapped silge + 1 on the rear door 1 1 Ø 1,5 x 1,2 m Cubic bales wrapped silage 1,2 x 0,9 x 2 m short strand < 30 cn + 1 on the rear door 1 1 short strand < 30 cr + 1 on the rear door Straw-spreading length 15 m 15 m Straw - Hay Product in bale Time Feeding or straw-spreading between 2 and 7 minutes maxi for a bale, according to material and packaging Loose food (dry food 30 or 35 %)



Prepare a right and precise feed

 Because a well measured feed is a quality feed, Lucas proposes a weighing system adapted to your needs. Except for Abeille® 12



Visualize the quantities mixed during the loading / unloading

Reliable weighing boxes...



Programmable weighing box (optional) EZ 3400

- Visualize in the menu the number of loading, the total weight and the average weight
- Up to 99 recipes from a list of 200 ingredients (EZ3400)

... can be equipped with second displays...



Wireless second display CAB CONTROL 400

- More comfort : visualize the weight from the tractor cab
- A visual and sound alarm : for a better control

... for a follow-up and a daily management of your farm

The boxes can be connected with the printer and / or with the PC You will like that follow and share easily your datas, and manage your feeds, herds and costs.






For shredding your bales

2 kinds of beater bars suitable to your needs :

Beater-bars Castor®+




Beater-bars for wrapped silage bales with long strands Fast and strong shredding of your fibers Except for Abeille® 12. Beater-bars Abeille® Special for short strands


Beater-bars for wrapped silage bales with short strands You do not have long strands, reach an unequalled performance in strawbedding ! Standard for Abeille[®] 12, available for Castormix[®]+ 180

For an optimized and fast shredding, our beater bars are equipped with :

V shaped knives



They cut wrapped silage and strands Their action is aggressive and effcient for saving time and for an optimal shredding



Regulating hydraulic comb



You can regulate the silage unloading according to the material and from the tractor cab It keeps the beater bar aggressive. It guarantees like that a better output and then a more efficient and faster shredding. Available for Castormix®+ 180 and 80. In series for Castormix®+ 60.

The chain-bed : to carry the foods up to the beater bars

Regulated chain-bed conveyor



Driving forward or reverse running

Splittable bars





The bars of the bed-chain can be dismantled easily ! They are not welded, but bolted and made in heavy steel tensile strength

Bed-chain tensioner



To adjust your bed-chain rapidly and simply from the outside your machine

LUCASC



Mix, and then feed and spread straw

Choice of the feeding chute






In order to answer your requirements we have developped 3 kinds of chute : Feeding and straw-bedding • Universal chute



Fluid and regular output, controlled from your tractor Swivelling 270° Except for Abeille® 12



Abeille[®] 12

Swivelling mixing chute



• Mixing canopy



• Right lateral chute



Regular feeding Straw-bedding can reach 18 m Only for Abeille® 12.

In order to have a supple and aired recycling mixing, a canopy is mounted on the back part of the tube.

You can choose two ways of feeding :

• Direct feeding



The foods are directly laid on the ground



The foods slide, and are then laid on the ground



Your dealer accompanies you

Your dealer, as a LUCAS partner, is staying at your disposal to help you by using your machine and for its maintenance. If necessary, the Lucas technicians intervene for your machine. Do not hesitate to contact them for :

Your filters



• Maintain your filters. Make one change per year

Your bed-chain



• Maintain your bed-chain For more efficiency, think to tighten it regularly ! The splittable bars of the bed-chain can be dismantled easily !

For an optimal service of spare parts, we work with a stock : For 95 % of the orders, the parts are dispatched at the latest the day following their receipt

Demonstrations

You are interested and want to see a machine working ? Do not hesitate to contact us



Please contact :

- your LUCAS dealer
- directly the firm LUCAS
- by mail commercial@Lucasg.fr
- or by phone **00 33 251654136**



Your knives



• Maintain your knives for a good cutting ! For a good functioning of the machine, replace the knives as soon as necessary.



Your LUCAS approved dealer is staying at your disposal for renovating the machine before reselling it

Distributed by :

		CASTORMIX®+ 180 ABEILLE® 180	ABEILLE [®] 12	CASTORMIX®+ 80	CASTORMIX®+ 60
CAPACITY	Tub Volume (m3)	17,5	12	7,4	6
	Mixing volume (m3)	18,7	11,8	7,9	6,45
	Loading capacity (m3)	16	10,5	6,7	5,25
	Inside length (m) (door or claw closed)	4,9	3,83	3,77	2,97
	Inside length (m) (open door)	6,9	5,63		
	Bales for loading Round / "bigs"	Ø 1,8 x 1,2 m L 2,8 x 1,2 x 1,2	Ø 1,8 m L 2, 8m	Ø 1,8 m L 2, 8m	Ø 1,8 m L 2, 8m
	Square	1,2 x 1,2 x 2,5 m	1,2 x 1,2 x 2,5 m	1,2 x 1,2 x 2 m	1,2 x 1,2 x 1,5 m
	Unloaded Weight (kg)	4550	3460	3300	2870
	Useful load (T)	6,3	5	3,3	2,2
	Axle	square of 90	square of 80	square of 70	square of 60
DIMENSIONS	Overall length (m)	7,7	6,8	5,84	5,09
	Overall height (m) canopy folded	2,82	2,7	2,35	2,33
	Overall height (m) canopy in mixing position	3,7	3,45	3,25	3,25
	Overall width (m)	2,4	2,65	2,31	2,31
	Silage unloading height (m)	3,5	3,5		
	Feeding height (m)	1,4	1/1,4	1,5	1,5
	Straw-spreading height (m)	3,2	1,9	2,5	2,5
	Range of straw-spreading (m)	15	18	15	15
OR I	Oil flow rate (L/mn)	15-45	15-45	20-45	20-45
	Minimum PTO (HP)	80	70	70	65
TR	Pressure (bars)	160/200	160/200	160/200	160/200
EQUIPMENTS	Comfort control	1	•	1	1
	Manual control	-	1	-	-
	Two-speed gearbox	1	1	1	1
	2nd control station	-	-	1	•
	Articulated coupling	-	-	1	1
	Fixed coupling	1	1	•	•
	Hydraulic stand	1	-	•	•
	Electric clutch	1	-	•	•
	Mixing hopper 500 L	-	-	-	•
	Not programmable weighing	•	-	•	•
	Programmable weighing	•	-	•	•
	Universal Swivelling chute	1	-	1	1
	Right lateral chute	-	1	-	-
	Swivelling mixing chute	-	•	-	-
	Extended chute U	-	-	•	•
	Mixing canopy	1	1	1	1
	Beater-bar Castor+	1	-	1	1
	Beater-bar Abeille	•	1	-	-
	Regulating hydraulic comb	•	-	•	1
	Regulated bed-chain	1	1	1	1
	Lifting rear door	•	-	-	-
	Hydraulic rear door not for loading	•		-	
	Round silage unloading claw	-	-	1	1
	Clean silage unloading deflector kit	-	-	•	•

In series • Optional equipment - Not available

CE These machines complies with the safety norms





Siège Social : 22 rue du stade - BP 9 - 85130 La Verrie - France - Tél. : +33 (0)2 51 65 41 36 - Fax : +33 (0)2 51 65 41 51 E-mail : lucasg@lucasg.fr - E-mail commercial : commercial@lucasg.fr - web : www.lucasg.com