CASTOR®+ R

Ē.,

Feeder - Straw bedder

Self-loading rear door Wrapped silage with long strands



Choose your machine in the more complete range of the market, and benefit from the experience of a leader !

The experience in the strawbedding's and feeding's service !

Thanks to an experience of 15 years, the Castor®+ range adapt to your farm : 2 kinds of beater bars for your feeds, and 6 volumes according to the size of your herd.

All our machines have been designed to reach an optimal production in a minimum of time :

- Easier loading
- Fast and efficient cutting and shredding/
- Feed all sorts of forage
- Spread straw simply and comfortably
- Quality feed

This optimization will allow you, breeder, to save time !

Castor[®]+ 80 - 8 m

Polyfeed[®] 12 - 12 m³

LUCAS.G : INVENTOR OF THE UNIVERSAL CHUTE

Castor®+ 60 - 6 m³



Castor®+ 180 - 18 m³



LUCASC

Castor®+ 20 - 2 m³

Castor[®]+ 30 - 3 m³

UCASC



Couple your machine and drive easily !



Réception DRIRE Drive an approved machine !

Choose the coupling corresponding to your machine and to your needs !

Articulated coupling



Adjustable, it adapts to all machines and allows manoeuvrability and comfort by driving. Follows completely the tractor.

Fixed coupling



Adjustable jib in 3 positions.



To stabilize your machine, on fixed coupling.

3 points coupling



Only for Castor®+ 20 (mounted machine).

Start and drive your Castor®+ R

Intuitive electric control

Comfort control



You can reach all functions with 3 fingers. Drive instinctively and supervise your work.



One button for one function. The **simplicity** in the control's service. Except for Castor®+180 and Polyfeed®12.



Manual control

Economy in control's service. Castor®+180 and Polyfeed®12.

Multifunctions display



Controls adapted to your expectations !





However your quantity of fibers is, you will find the suitable volume for you !

Castor®+ 20




The Castor®+ power available for mounted model ! A 2 m³ machine equipped with a Castor®+ beater-bar





The best-seller of feeders - straw bedders ! A 3 m³ machine equipped with a Castor®+ beater-bar





Castor[®]+ 60 R



2 models for differents needs : available with only one chain-bed or with 2 independent chain-beds «twin». A 6 m³ machine equipped with a Castor®+ beater-bar

Castor®+ 60



Castor®+ 60 Twin


Castor[®]+ 180 R, Polyfeed[®] System




Castor®+ 80 R



The new volume of the Castor+ range ! A 8 m³ machine equipped with 2 Castor®+ beater-bars







Polyfeed[®] 12



15 years experience in straw-bedding's service ! A 12 m³ machine for wrapped silage with short strands equipped with 3 Polyfeed[®] beater-bars



A big model for big feeds ! A 18 m³ machine equipped with either 3 Castor[®]+ beater bars, or 3 Polyfeed[®] beater bars Ideal for important work of straw-bedding !







Load your foods







The doors



Choose a door suitable to your fodder. Self-loading rear door 600 kg or 1200 kg. Reliable and strong. It is equipped with a roll bar that enables a easier loading of the bales

Manual door



Only for Castor[®]+180 and Polyfeed[®] 12.

Lifting rear door




For Castor®+ 180.

Benefit from equipments, to make your loading easier

Mixing hopper



For adding your dry foods, we propose a mixing hopper 500 L Available for Castor+ 60 and 30





Available for Castor®+ 80, 60 and 30. In series for Castor+ 180 and Polyfeed with self-loading rear door



For shredding your bales

2 kinds of beater bars suitable to your needs :

Castor®+ beater-bars



Beater-bars for wrapped silage bales with **long strands.** Fast and strong shredding of your fibers !

Polyfeed[®] beater-bars

Special for short strands







Beater-bars for the short strands. You do not have long strands, reach an unequalled performance in straw-bedding ! Available for Castor®+ 180. Standard for Polyfeed® 12.

For an optimized and fast shredding, our beater bars are equipped with :

V shaped knives



They cut wrapped silage and strands. Their action is aggressive and effcient for **saving time** and for an **optimal shredding**.





You can regulate the shredding according to the material and from the tractor cab. It keeps the beater bar aggressive. It guarantees like that a **better output** and then a more efficient and faster shredding. Available for CASTOR®+ machine.

The chain-bed : to carry the foods up to the beater bars

The bars of the bed-chain can be


dismantled easily ! They are not welded, but bolted and made in

heavy steel tensile strength.

Chain-bed

Forward or reverse running.

Splittable bars





To adjust your chain-bed rapidly and simply from the outside your machine

Twin chain-bed



Only for Castor®+ 60 2 chain-beds which can run independently or simultaneously.

Advantages : • To load 3 round bales ; The first bale is in contact with the beater-bar, when the two other bales do not move and do not press on the bale being shredded. • To load 2 cubic bales of straw : the front chain-bed is carrying the bale up to the beater-bar, while the second chain-bed is stopping. The back chain-bed will be attacted whom the draw doridor to sproad will be started when the driver decides to spread straw with the second bale. • To exert less stress on the chain-bed because only the half of the useful load is moving.

Feed your foods

Choice of the chute for feeding







In order to answer your requirements we have developped two kinds of chute :

Right lateral chute




A regular feeding. Straw spreading till 18 meters.

Universal chute



Fluid and regular output, controlled from your tractor. Swivelling 270°.



You can choose two ways of feeding :

• Direct feeding



The foods are directly laid on the ground.

• Feeding via the slide



The foods slide, and are then laid on the ground.



Spread straw your farm

You can spread straw 270°



Straw-spreading up to 15 m with universal chute or 18 m with right lateral chute. Fluid and regular straw-bedding !

Dimensions of the models







Polyfeed®12





l : 3,77 m - L : 1,98 m - H : 2,43 m



Castor®+ 180/Polyfeed® System



l:7,77 m - L:2,40 m - H:2,82 m





Loading



Feeding



Straw-bedding







Castor®+ R performance

			Castor®+180 Polyfeed® 180	Polyfeed® 12	Castor®+ 80	Castor®+ 60	Castor®+ 60 Twin	Castor®+ 30	Castor®+ 20
Feeding or	Capacity of	Round bale	2		1	1	2 Ø 2 m	1Ø1,8	
straw-bedding	bales loading	or straw	+ 1 on	2	+ 1 on	+ 1 on	or 2 Ø 1,5	or 1 Ø 1,5	1
		Ø 2 m maxi	R door		R door	R door	1 + 1 on R door	1 + 1 on R door	
		Cubic bale	2	2	1	1	2	1	1
		hay or straw	+ 1 on						
		1,2 x 0,9 x 2,5 m	R door						
		Square bales hay or straw 1,2 x 1,2 x 2,5 m	1 + 1 on R door	1	1	1	1	1	1
		Round bale	1 + 1 on R door	1	2	1	2	1	1
		wrapped silage		short strand	+ 1 on	+ 1 on	+ 1 on	+ 1 on	
		Ø 1,5 x 1,2 m		< 30 cm	R door	R door	R door	R door	
		Cubic bale wrapped silage 1,2 x 0,9 x 2 m	1 + 1 on R door	1 short strand < 30 cm	1 + 1 on R door	1	2	1	1
	Straw-spreading length	Straw - Hay	18 m	18 m	15 m	15 m	15 m	15 m	15 m
	Time	Product in bale Loose food (dry food 30 or 35%)	Feeding or straw-spreading between 2 and 7 minutes maxi for a bale, according to material and packaging						



Your dealer accompanies you

Your dealer, as a LUCAS partner, is staying at your disposal to help you by using your machine and for its maintenance. If necessary, the Lucas technicians intervene for your machine. Do not hesitate to contact them for :

Your filters



• Maintain your filters. Make one change per year

Your bed-chain



• Maintain your bed-chain For more efficiency, think to tighten it regularly ! The splittable bars of the bed-chain can be dismantled easily !

For an optimal service of spare parts, we work with a stock : For 95 % of the orders, the parts are dispatched at the latest the day following their receipt

Demonstrations

You are interested and want to see a machine working ? Do not hesitate to contact us



Your knives



• Maintain your knives for a good cutting ! For a good functioning of the machine, replace the knives as soon as necessary.



Your LUCAS approved dealer is staying at your disposal for renovating the machine before reselling it

Please contact :

- your LUCAS dealer
- directly the firm LUCAS
- by mail commercial.france@Lucasg.fr
- or by phone **00 33 251654136**



CASTOR® + R Feeder - Straw bedder Self-loading rear door **SPECIFICATIONS**

			Castor®+180 Polyfeed® 180	Polyfeed [®] 12	Castor®+80	Castor®+60 Castor®+60 Twin	Castor®+ 30	Castor®+ 20
CAPACITIES	Tub volume (m ³)		17,5	12	7,4	6	3,2	NC
	Loading capacity (m ³)		16	10,5	6,7	5,5	2,75	NC
	Inside length (m)	closed door	4,9	3,83	3,65	3,08	1,45	1,08
		open door	6,9	5,63	4,72	4,43	2,8	2,85
	Bales for loading	Round / «bigs»»	Ø 1,8 x 1,2 m / L 2,8 x 1,2 x 1,2 m	Ø1,8 /L2,8 m	Ø 1,8 /L 2,8 m	Ø 1,8 / L 2,8 m	Ø 1,8 / L 2,8 m	Ø 1,8 x 1,2 m / L 2,8 x 1,2 x 1,2 m
3		Square	1,2 x 1,2 x 2,5 m	1,2 x 1,2 x 2,5 m	1,2 x 1,2 x 2,5 m	1,2 x 1,2 x 2,5 m	1,2 x 1,2 x 2,5 m	1,2 x 1,2 x 2,5 m
	Unladen weight (kg)		4500	3460	3040	2620	1970	1600
	Useful load (T)		7,1	5	4,4	2,8	2,3	0,7
	Axle / square of		square of 90	square of 80	square of 70	square of 60	square of 60	
	Overall length (m)		7,7/9,55	6,8	5,97/7,55	5,41	3,77	2,77/4,25
	Overall height (m)	Right lateral chute	2,88	2,7	2,25	2,11	2,07	
		Universal chute	2,88	2,7	2,88	2,46	2,43	2,38
	Overall width (m)	Right lateral chute	2,45	2,48/3,24	2,5	2,27	2,21	
NS NS		Universal chute	2,4		2,3	2,12	1,98	1,86
DIMENSIONS	Distribution height (m)	Right lateral chute	0,9	1,4	1,01	0,97	0,97	
IEN	Distribution neight (m)	Universal chute	1,4		1,3	1,5	1,5	NC
D	Straw-spreading height (m)	Right lateral chute	1,9	1,9	1,88	1,6	1,6	
	Straw-spreading height (III)	Universal chute	3,2		NC	2,5	2,5	2,5
		Right lateral chute	18	18	18	18	18	
	Straw-spreading length (m)	Universal chute	15		15	15	15	15/18 (depending on environment)
			45.45	45.45	45.45	15-45	15-45	
þ	Oil flow rate (L/min)		15-45	15-45	15-45		(30-45 if mixing hopper)	30-60
IRACTOR	Tractor power (HP)		80	65	70	65	65	65
Ë	Operating pressure (bars)		160/200	160/200	160/200	160/200	160/200	160/200
	Comfort control		•	•	1	1	1	1
	Intuitive control			-	•	•	•	•
	Manual control		1	1	-	-	-	-
	Two-speeds gearbox 2 rd control station Articulated coupling Fixed coupling 3 points coupling Hydraulic stand		1	1	1	1	1	1
			-	-	•	•	•	•
			-	-	1	1	1	-
			1	1	•	•	•	-
			-	-	-	-	-	1
			1	-	•	•	•	-
Ś	lectric clutch		•	-	•	•	•	-
EQUIPMENTS	Mixing hopper 500 L		-	-	-	•	•	-
N N	Universal chute		•	-	•	•	•	1
5	Right lateral chute		1	1	1	1	1	-
g	Chute lengthen		-	-	•	•	•	•
	Beater-bar Castor®+		Beater-bar	-	1	1	1	1
	Beater-bar Polyfeed®		at your choice	1	-	-	-	-
	Regulating hydraulic comb		•	-	1	1	1	1
	Regulated bed-chain		1	1	1	· ·	1	· ·
	Bed-chain Twin		-	-	-	•	-	-
	Self-loading rear door 600 kg or 650 kg		-	-	1	-	1	1
	Self-loading rear door 1200 kg		-	-	•	•	•	-
	Lifting rear door		•	-	-	-	-	-
	Hydraulic rear door not for loading -		•	-	-	-	-	-
		ч -	•	· · ·		-	-	I

For all models • Option - Unvailable





CE These machines complies with the safety norms.

Distributed by :

S.A.S. au capital de 1 000 000 € - RCS LA ROCHE SUR YON B 547 150 730 - SIRET 547 150 730 00026 – Code NAF 2830 Z Code TVA intra communautaire FR 63 547 150 730

Siège Social : 22 rue du stade - BP 9 - 85130 La Verrie - France - Tél. : +33 (0)2 51 65 41 36 - Fax : +33 (0)2 51 65 41 51 E-mail : lucasg@lucasg.fr - E-mail commercial : commercial@lucasg.fr - web : www.lucasg.com